



PLEASE NOTE THAT WE HAVE INSTALL VIDEOS FOR MANY MODELS ON GOOGLE VIDEO AND YOUTUBE.COM. SEARCH UNDER "WIND DEFLECTOR"

# Wind Deflector BMW (E36) 325, 323, M3 1993 to 1999 Installation Guide

**START BY PUTTING YOUR TOP DOWN AND LEAVING THE LID UP.**

HAVE A FRIEND HELP YOU INSTALL THE WIND DEFLECTOR THE FIRST COUPLE OF TIMES. AFTER THAT YOU WILL BE ABLE TO PUT IT IN AND OUT BY YOURSELF IN MINUTES.

**STEP 1: MAKE SURE THE BLACK HOOKS ARE FACING UP**



**STEP 2: PULL OUT THE WIRE BRACKET OUT FROM THE CLOSED POSITION**



LOVE THE DRIVE COPYRIGHT 2007, WWW.LOVETHEDRIVE.COM, PRINTED IN CANADA PAGE 1

**STEP 3: FROM THE SIDE OF YOUR CAR PLACE THE WIND DEFLECTOR IN THE BACK SEAT AREA OF YOUR CAR**

**STEP 3 CONT: ALIGN THE BLACK HOOKS, AT THE REAR OF THE WIND DEFLECTOR SO THAT THEY HOOK ON TO THE QUARTER TRIM PANEL. IN THE AREA COVERED BY THE TOP LID**



**STEP 3 CONT: MAKE SURE BOTH BLACK HOOKS ARE ATTACHED TO THE TRIM PANEL AND THEN CLOSE TOP COVER LID TO HOLD BLACK HOOKS IN PLACE**



**STEP 4: THE WIRE HOOK ONCE PULLED OUT, WILL REST ON THE TRIM PANEL**



**STEP 4 CONT: PULL THE WIRE BRACKET BACK AND LOWER TO LINE UP WITH THE HOLE IN THE QUARTER TRIM PANEL**



**STEP 4 CONT: RELEASE WIRE BRACKET SO IT ENTERS HOLE**



**STEP 4 CONT: REPEAT ON THE OTHER SIDE AND YOU ARE READY TO GO**



**NOW YOU ARE READY TO LOVE THE DRIVE  
[WWW.LOVETHEDRIVE.COM](http://WWW.LOVETHEDRIVE.COM)**