



PLEASE NOTE THAT WE HAVE
INSTALL VIDEOS FOR MANY
MODELS ON GOOGLE VIDEO AND
YOUTUBE.COM. SEARCH UNDER
"WIND DEFLECTOR"

Wind Deflector BMW (E30) 325, 1987 to 1992 Installation Guide

START BY PUTTING YOUR TOP DOWN AND
LEAVING THE LID UP

STEP 1: PULL OUT THE WIRE BRACKET FROM
THE CLOSED POSITION



STEP 2: PLACE THE WIND DEFLECTOR IN
THE BACK SEAT OF YOUR CAR



LOVE THE DRIVE COPYRIGHT 2007 WWW.LOVETHEDRIVE.COM PRINTED IN CANADA PAGE 1

FROM THE SIDE OF YOUR CAR WITH THE WIND DEFLECTOR IN THE BACK SEAT AREA OF YOUR CAR

STEP 3: PLACE THE BACK BRACKET BEHIND THE DIP IN THE TRIM PANNEL. REPEAT ON THE OTHER SIDE



STEP 3 CONT: CLOSE TOP COVER LID TO HOLD BLACK HOOK IN PLACE



STEP 4: THE WIRE HOOK ONCE PULLED OUT, WILL REST ON THE TRIM PANEL, JUST ABOVE THE SEAT BELT, NEAR THE FRONT SEATS



STEP 4 CONT: PULL THE WIRE BRACKET BACK AND FORWARD THEN LOWER IT TO LINE UP WITH THE SPACE BESIDE SEATBELT



STEP 4 CONT: DIRECT THE WIRE BRACKET INTO THE SPACE BEHIND THE SEAT BELT.



STEP 4 CONT: REPEAT ON THE OTHER SIDE AND YOU ARE READY TO GO



NOW YOU ARE READY TO LOVE THE DRIVE
WWW.LOVETHEDRIVE.COM