



PLEASE NOTE THAT WE HAVE  
INSTALL VIDEOS FOR MANY  
MODELS ON GOOGLE VIDEO AND  
YOUTUBE.COM. SEARCH UNDER  
"WIND DEFLECTOR"

# Wind Deflector Mercedes 380sl, 450sl, 560sl (1973 to 1988) Installation Guide

**START BY PUTTING YOUR TOP DOWN.**

THE WIND DEFLECTOR  
ATTACHES TO THE  
CONVERTIBLE TOP LID



START BY PLACING THE WIND DEFLECTOR IN  
THE AREA BEHIND THE FRONT SEATS ON TOP OF  
THE LID



LOVE THE DRIVE COPYRIGHT 2007, WWW.LOVETHEDRIVE.COM, PRINTED IN CANADA PAGE 1

THE WIND DEFLECTOR IS HELD IN PLACE BY TWO LATCHES ON EACH SIDE AND TWO BRACKETS IN THE BACK. ONCE YOU HAVE PLACED THE WIND DEFLECTOR IN PLACE MAKE SURE THAT IT IS STRAIGHT.



MAKE SURE THAT THE BACK BRACKETS ARE TOUCHING THE BACK OF THE LID. THE BRACKETS AND LATCHES ARE COATED IN A SOFT PLASTIC SO THEY WILL NOT MARK OR SCRATCH THE LEATHER.



THE FRONT LATCHES ARE ON EACH SIDE AND LATCH ON TO THE BOTTOM OF THE CONVERTIBLE TOP LID



MAKE SURE THE LATCH IS UNDER THE LID AND THEN PULL UP. IT IS GOOD TO HOOK THE LATCHES AT THE SAME TIME.



ONCE YOU HAVE LATCHED BOTH SIDES YOU ARE READY TO GO DRIVING



LIFT THE WIND DEFLECTOR UP AND YOU ARE NOW READY TO GO DRIVING



WHEN YOU ARE NOT USING THE WIND DEFLECTOR IT CAN BE STORED IN ITS STORAGE BAG



**NOW YOU ARE READY TO LOVE THE DRIVE**  
**[WWW.LOVETHEDRIVE.COM](http://WWW.LOVETHEDRIVE.COM)**