



PLEASE NOTE THAT WE HAVE  
INSTALL VIDEOS FOR MANY  
MODELS ON GOOGLE VIDEO AND  
YOUTUBE.COM. SEARCH UNDER  
"WIND DEFLECTOR"

# Wind Deflector Sebring 1996 to 2000 Installation Guide

**START BY PUTTING YOUR TOP DOWN**

**STEP 1:**  
WHEN YOUR WIND DEFLECTOR WAS SHIPPED  
WE NEEDED TO STORE THE FRONT BRACKETS  
FACING IN.

**STEP 1 CONT**  
LOOSEN ALL THREE SCREWS, TURN THE  
BRACKET SO IT FACES OUT AND THEN TIGHTEN.  
REPEAT TO THE OTHER SIDE



**STEP 2: UNFOLD THE BOTTOM PANELS AND PLACE THE WIND DEFLECTOR IN THE BACK SEAT AREA. KEEP THE TOP PANEL FOLDED DOWN**



YOUR WIND DEFLECTOR HAS FOUR BRACKETS TWO IN THE FRONT AND TWO IN THE BACK THAT ATTACH TO THE TRIM PANEL

**STEP 2 CONT: THE FRONT BRACKETS REST ON THE TOP OF THE SIDE TRIM PANEL.**



**STEP 2 CONT: THE BACK BRACKETS ARE HOOKS THAT ATTACH TO THE SIDE TRIM PANEL NEAR THE BACK SEAT.**



**WITH YOUR WIND DEFLECTOR YOU RECEIVED TWO SNAP SCREWS. YOU WILL NEED A #2 PHILIPS SCREW DRIVER TO REPLACE TWO SCREWS ON YOUR CAR**



**STEP 3: THE TWO SCREWS THAT NEED TO BE REPLACED ARE ON THE TRIM PANEL BESIDE THE TOP OF THE BACK SEAT.**



**STEP 3 CONT: UNSCREW BOTH OF THE BLACK SCREWS ON EACH SIDE OF THE CAR AND REPLACE THEM WITH THE TWO SNAP SCREWS PROVIDED. YOU WILL ONLY HAVE TO DO THIS ONCE**



**STEP 3 CONT:** THE BACK BRACKET HAS A STRAP WITH A FEMALE SNAP WHICH ATTACHES TO THE MALE SNAP ON THE TRIM PANNEL.



**STEP 3 CONT:** THE SNAP STRAP IS BEST ATTACHED FROM UNDERNEATH THE WIND DEFLECTOR. ATTACH THE SNAP STRAP ON BOTH SIDES OF THE CAR ON THE QUARTER TRIM PANNEL.



**STEP 4:**  
NEXT ATTACH THE FRONT HOOK STRAP TO THE BOTTOM SIDE OF THE TRIM PANNEL. THESE STRAPS ATTACH TO THE FRONT BRACKET OF WIND DEFLECTOR



**STEP 5:** NEXT ATTACH THE TWO BACK HOOKS TO EACH SIDE OF THE BACK OF THE TRIM PANNEL BY THE BACK SEAT. THESE STRAPS ATTACH TO THE MIDDLE OF THE WIND DEFLECTOR



**STEP 6:** NEXT ATTACH ALL THE STRAPS TO THE BUCKLES AND THEN PULL THE STRAPS TIGHT TO SECURE IN PLACE.



WHEN YOU HAVE THE STRAPS IN PLACE IT WILL LOOK LIKE THIS PHOTO.



*YOUR WIND DEFLECTOR STORES IN YOUR TRUNK WHEN NOT IN USE. BUT REMEMBER THAT YOU HAVE TO REVERSE THE FRONT SIDE BRACKETS*



*TO REVERSE THE FRONT BRACKETS, TURN THE THUMB SCREWS COUNTER CLOCKWISE TO LOOSEN, THEN TURN THE BRACKET TO FACE INSIDE. THEN REINSTALL THE THUMB SCREWS BY TURNING THE SCREWS CLOCKWISE*



*NOW WITH YOUR WIND DEFLECTOR UP YOU ARE READY TO GO DRIVING!*



*NOW YOU ARE READY TO LOVE THE DRIVE  
[WWW.LOVETHEDRIVE.COM](http://WWW.LOVETHEDRIVE.COM)*