



We have an install video guide on our website. Also feel free to call or email us if you have any questions  
1-855-457-5683  
information@lovethedrive.com

# BMW 3 (E93) 2007 to 2014

- \* You can raise and lower your convertible top with the wind deflector installed.
- \* The wind deflector will fit in the trunk when the Convertible Top is UP or You can use the Passageway between the Trunk and the backseat. But the rear seat has to be folded down for the wind deflector to fit thru.
- \* **The Wind Deflector DOES NOT Fit in the Trunk with the Top Down**

Start by lowering your top and moving the front seats all the way forward.

Your BMW 3 is designed to be fitted with a wind deflector. There are two holes on each side of the rear trim panel. The front and rear barrel bolts fit into these holes.



Start by extending the front and rear barrel bolts on one side of the wind deflector. Turn the handles so they will face down, this locks the bolts into place. These bolts will slide into the holes on the opposite side of the car from which you are standing.



Lower the wind deflector into the backseat area and insert the front bolt into the hole in the time panel and then insert the rear bolt.



Now lower the wind deflector into the back seat area so the front barrel bolt is in line with the front hole. Slide the bolt forward into the hole and turn the handle down to lock the bolt.



Next reach back and slide the rear bolt into the rear hole and turn the handle down to lock the barrel bolt.



When you are finished please double check to that all four handles are turned downwards so the barrel bolts are in the locked position.



Your Wind Deflector comes with a storage bag included. Your wind deflector will fit in the trunk with the Top UP.



The other option is to use the Passageway between the Trunk and backseat as shown in the photo. But the backseat must be lowered flat so no one can sit the backseat.

