



We have our video install guides on our website and on youtube.com Also feel free to call or email us if you have any questions 1-855-457-5683 information@lovethedrive.com

Mercedes E-Class 2010 to 2016 Wind Deflector Install Guide Design by Love The Drive

- * You can raise and lower your convertible top with the wind deflector installed.
- * The wind deflector will fit in the trunk when not in use.

Start by lowering your top and titling the front seats forward.

Your Mercedes Convertible is designed to fit a wind deflector. There are two holes in the trim panels in the rear seat area.



The Rear brackets slide into the slots where the rear seatbelts come out from the rear seat.



Start by lowering the wind deflector into the rear seat area. Slide the rear brackets into the rear seat seatbelt slots. Then slide the front bolts into the holes in the trim panels. Turning the handles down to lock the wind deflector in place.



Your wind deflector has bolts in the front that slide into the holes in the each trim panel



Turn the bolt handle down to lock the bolt in place. Turn the handle towards the front to slide the bolt into and out of the hole.



Insert the rear brackets into the rear seatbelt slots



Your Wind Deflector will fit in your trunk. It also comes with a free storage bag for use when the wind deflectors needs to put in the trunk. Once you rotate one of the rear brackets



Once you rotate **ONE** of the rear brackets, loosen & remove the two thumbscrews. Rotate the rear bracket 180% and then replace and tighten the thumb screws.



Start by inserting the end of the wind deflector with the rear bracket that has been Rotated (bracket should be facing up) in to the Passenger side of the Trunk



On the driver side raise the wind deflector so that it is close to the front of the trunk and lower the wind deflector into the Trunk

